RACOR®

Parker Filtration

Parker Hannifin Corporation
Racor Division
P.O. Box 3208, 3400 Finch Rd.
Modesto, CA. 95354 USA
209/521-7860

Fax 209/529-3278
800/344-3286
www.parker.com/racor

THIS KIT INCLUDES THE FOLLOWING:

1) LID GASKET P/N 15005 (USED ON ALL 500 UNITS).
2) .620" DIAMETER T-HANDLE O-RING P/N 11350 (USED ONLY ON 500FG UNITS).

TO INSTALL REPLACEMENT ELEMENT:

1) REMOVE T-HANDLE AND LID.
2) USING ELEMENT BAIL, CAREFULLY REMOVE CONTAMINATED ELEMENT WITH A TWISTING MOTION AND DISCARD.
3) INSTALL REPLACEMENT ELEMENT BY POSITIONING ELEMENT OVER RETURN TUBE AND PUSHING ELEMENT DOWN UNTIL IT BOTTOMS.
4) TOP OFF BY POURING CLEAN DIESEL FUEL INTO FILTER CAVITY UNTIL FULL.
5) REMOVE AND DISCARD OLD LID GASKET AND CLEAN SEAL GLAND OF ANY DIRT OR DEBRIS. LUBRICATE NEW LID GASKET WITH CLEAN DIESEL FUEL PRIOR TO INSTALLATION.
6) REMOVE AND DISCARD OLD T-HANDLE O-RING. CLEAN O-RING GLAND OF ANY DIRT OR DEBRIS. LUBRICATE NEW O-RING WITH CLEAN DIESEL FUEL PRIOR TO INSTALLATION.
7) REPLACE LID, T-HANDLE AND HAND TIGHTEN.

KIT P/N 15211